



# Technical Specification

	<b>BF32H2322CGKB</b> <b>BF32H2352CGKB</b>
Energy Efficiency Class (SDR)	E
Power consumption (SDR)	25 W
Screen resolution (pixels)	1366 x 768
Screen Size (diagonal)	81 cm / 32 inches
RF	75 ohm Antenna / Analog / DVB / Satellite
Inputs	3 x HDMI, 2 x USB, 1x Micro SD card slot, 1 x RJ45 LAN/Ethernet, 1x Composite/CVBS Video & Component/YPbPr input, 1 x L/R Audio input for Composite/CVBS & Component YPbPr
Sound Outputs	1 x Digital Optical Audio output, 1 x 3.5mm Headphone
Speaker*/ Amplifier Watts (RMS)	2 x 10 / 2 x 8
Voltage and power consumption	AC 220V ~ 240V; 50Hz 25/40/65W (home mode/standby/max) (0.5W in Standby)
Dimensions including stand (mm)	730W x 471H x 169D
Net weight (Kgs)	4.6
Wall Mounting	VESA 200 x 100 (mm)

SOUND SYSTEM BY



JBL is trademark of HARMAN International Industries, Incorporated, registered in the United States and/or other countries.



Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.



The terms HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.



# Quick Start Set Up Guide

For information on using the TV's features, please refer to the Operating Instructions.

## Model Numbers

**BF32H2322CGKB**

**BF32H2352CGKB**

## Quick & easy guide for setting up your TV

What is included in the box

Using the remote control

Setting up the TV for the first time - including attaching the stand

Connecting other devices to the Television

## Need help setting up or using your TV?

Please contact the UK & ROI Helpline\*

Telephone UK 0330 024 0802 or ROI 01443 3940

Online support at: [www.umc-uk.co.uk](http://www.umc-uk.co.uk)

Email support at: [service@umc-uk.co.uk](mailto:service@umc-uk.co.uk)

\*Calls to 0330 numbers are charged at standard call rates and are included as part of any bundled minutes with your phone provider. Calls to the ROI number are charged at the local call rate. The telephone opening hours are:

Monday to Friday: 8.30am – 6pm

Saturday: 9am – 5pm

Bank Holidays: 10am – 4pm

Closed Christmas and New Years day.



## Sky Remote Code



If you wish to use your Sky remote to operate the TV's basic functions, you will need a Sky remote control (Revision 9 or later) and you will need to program it with the code 2134. If you wish to use your Sky Q remote to operate the TV's basic functions, you will need to program it with the code 4170.



- 1 ON/OFF** - Switch on the TV when in standby or vice versa. **FREEVIEW PLAY** - Access the Freeview Play apps.
- 2 MUTE** - Mute the sound or vice versa. **NUMBER BUTTONS** - 0-9 to select a TV channel directly. **TV GUIDE** - Opens the 7 day TV guide (digital TV mode).
- 3 VOL (+/-)** - To increase/decrease the sound level. **PICTURE** - Scrolls through picture mode options. **SOUND** - Scrolls through sound mode options. **SOURCE** - To display the input/source menu. **CH (+/-)** - To increase or decrease the channel being watched. **MENU** - To display OSD menu. **EXIT** - To exit all menus. **(FAV/OK)** - Allows you to navigate the on-screen menus and adjust the system settings to your preference. **BACK** - To go back a previous step. **FAV** - To display favourites menu.
- 4 INFO** - Press once for now/next channel information. **TEXT** - To enter/exit Text. **SUBTITLE** - To switch the dialogue at the bottom of the screen (on/off). **TV** - To switch to Digital Channels. **YOUTUBE** - Access the Youtube App. **NETFLIX** - Access the Netflix App. **SMART** - Access the Blaupunkt Smart Portal. **RECORD** - Access the USB record function. **REC LIST** - Opens the list of what has been previously recorded. **REPEAT** - To repeat playback. **ANGLE** - Select different angle of DVD. **A-B** - Press once to set point, press a second time to return to point. **GOTO** - To go to a specific chapter. **REPEAT** - To repeat playback. **REPEAT** - To repeat playback.

## What is included in the box

- Accessories included with this TV are the following accessories
- 1 x Quick Start Guide
  - 1 x Stand Installation pack
  - 1 x Safety Leaflet
  - 1 x Remote Control & 2 x AAA Batteries

## Additional Accessories



If you don't have the RF cable shown below, then you can purchase one from [www.umc-uk.co.uk/cables](http://www.umc-uk.co.uk/cables) If you are intending to connect your TV to an RF socket in order to receive Freeview you will need this cable.



Freeview Play brings together live TV viewing with "catch up" TV services such as BBC iPlayer, ITV player, All 4 and My5. The Freeview Play app features a carousel of genres to select from when searching for programmes, such as sport, comedy, dramas and soaps, etc. Content is made up from recommendations of the major broadcasters and offers an alternative means of searching.

Note that to use the full functionality of Freeview Play your set must be connected to the internet.

## Microsoft PlayReady™

This product contains technology subject to certain intellectual property rights of Microsoft. Use or distribution of this technology outside of this product is prohibited without the appropriate license(s) from Microsoft. Content owners use Microsoft PlayReady™ content access technology to protect their intellectual property, including copyrighted content. This device uses PlayReady technology to access PlayReady-protected content and/or WMDRM-protected content. If the device fails to properly enforce restrictions on content usage, content owners may require Microsoft to revoke the device's ability to consume PlayReady-protected content. Revocation should not affect unprotected content or content protected by other content access technologies. Content owners may require you to upgrade PlayReady to access their content. If you decline an upgrade, you will not be able to access content that requires the upgrade.

Please save your box/package as you will need this in the event of warranty/service repair or support. We are unable to carry out warranty/service if you are unable to package it correctly. The safest way to package your item in the event of warranty/service repair is in its original box/packaging.

## Online Manual

To launch the Online Manual, press the [MENU] button and then select Settings > Setup > Help Information

## Using the remote control

# Setting up the TV set for the first time


To obtain a copy of your Operating Instructions, please go to: [https://www.umc-uk.co.uk/instruction-manuals/Blaupunkt-Television\\_information.html](https://www.umc-uk.co.uk/instruction-manuals/Blaupunkt-Television_information.html)

Or scan this QR code:




## 1 Fitting the stand


TV panel must be facing downwards.  
For the stand installation, there is one type of screw provided as shown below.  
To complete the stand installation you will require a cross head screw driver. Place the TV set on a flat and clean surface with the panel facing downwards to avoid damage.




4 x Used for attaching the stand to the TV set (fig.2)



Place the TV set on a flat and clean surface with the panel facing downwards to avoid damage. Ensure the panel is not resting on any object.



Feet should be pointing away from each other as shown in the picture above.




When the stand feet are in the correct position, secure the stand feet to the TV set using the 4 screws provided.



Register For Your  
**BLAUPUNKT**  
Manufacturers Warranty

Register your manufacturers guarantee online within 14 days of purchase at [www.registertv.co.uk/blaupunkt](http://www.registertv.co.uk/blaupunkt)

## 2 Connecting your set




Outdoor Digital TV Aerial

- 1 Connect the TV to your power socket.
- 2 If you wish to use the TV to receive Freeview/Saorview channels, connect the RF input from the TV to your outdoor Digital TV aerial. If you do not wish to receive Freeview/Saorview, skip this step.

## 3 Powering On the TV

TV Control Stick



Switch on the television by pressing the TV control stick located on rear right side of the TV set.

Remote Control: Installing Batteries



Insert the batteries supplied into the remote control and press the standby button to power on the TV.

## Wall Mounting the TV




Image for illustration only.

- 1 Remove the four screws that are supplied in the wall mounting holes.
- 2 The wall mount can now be easily attached to the mounting holes on the rear of the TV.
- 3 Install the wall mounting bracket to the television as advised by the bracket manufacturer.

The picture shows the use of spacers, which are not applicable to all sets/installations.

## 4 First time installation

Basic installation steps are shown below. These may vary slightly depending on model.



Introduction & Language

When the set first turns on, it enters the First Time Installation mode. This can be restarted by restoring the set to default settings in the 'About TV' Menu. Select your preferred on-screen display language. This will change the language in which the menus and associated information is displayed in.



Time Zone

Set the Time Zone in which the TV will reside. This may be dependent on the country you select in step 2.



Set up Netflix

If you have a Netflix account, it can be set up on the television here. Once set up and validated, the First Time Installation returns to the next step.



Country

Select the correct country in which the set will be used in. This will enable the set to correctly install the functions applicable in the country of use.



Updates Notice

You will need to agree to certain information collection for the TV set to operate as intended.

**Note:** In home mode, the TV will switch off automatically after 4 hours in the event that no buttons are pressed on the TV or remote control.



TV Mode

**Home Mode:** For normal use, by default it is set to a power saving mode which reduces the energy used by up to 25% (by reducing the power to the LED/LCD panel). This can be changed in the picture mode settings.



PIN

This needs to be set to establish parental controls.



Network Set Up


You can connect the TV to your broadband router or wireless network in order to take advantage of the Smart functions. If you connect the TV to your router using an Ethernet cable, the Wifi set up will be skipped.



Channel Scan

Choose to install terrestrial channels via Digital or Analog signals.  
**Note:** Analog signals in the United Kingdom have been turned off. Only Digital signals are available.

## Connectivity



A	Ethernet/LAN*	Network Connection	H	RF In	RF / TV Aerial input
B	Digital Audio	Digital Optical Audio Output	I	HDMI 1 (ARC)	HDMI Input with ARC
C	HDMI 3	HDMI Input	J	Earphones	Earphones Input
D	HDMI 2	HDMI Input	K	Service Input	Input is used only by service centres
E	L/R	Audio shared for video/Composite and component/YpBPr	L	CI Card In	Common Interface Module
F	Video/YpBPr	Video Input (green) and HD input (Ypbpr)	M	TF Card In	Micro SD Card Input
G	SAT In	Satellite Input	N	USB 2.0	USB 2.0 input x2