

# Technical Specification

## Product fiche

|  |                                      |
|--|--------------------------------------|
| Trademark  | Sharp                                |
| Model ID   | 55BJ2K<br>55BJ3K<br>55BJ4K<br>55BJ5K |
| Energy efficiency class  | A                                    |
| Visible screen size (diagonal)   | 139 cm / 55 inches                   |
| On-mode power consumption  | 110.0 W                              |
| Annual energy consumption *1   | 161 kWh                              |
| Standby power consumption *2   | <0.50 W                              |
| Off mode power consumption   | n/a                                  |
| Screen resolution  | 3840 (H) x 2160 (V)                  |
| *1: Energy consumption XYZ kWh per year, based on the power consumption of the television operating 4 hours per day for 365 days. The actual energy consumption will depend on how the television is used. |                                      |
| *2: When the TV is turned off with the remote control/standby button and no function is active.  |                                      |

|                                 |  |
|---------------------------------|--|
|                                 | 55BJ2K<br>55BJ3K<br>55BJ4K<br>55BJ5K   |
| RF                              | 75 ohm Antenna / Analog / DVB / Satellite  |
| Inputs                          | 3 x HDMI, 3 x USB, 1 x SD card reader,<br>1 x RJ45 LAN/Ethernet,<br>1 x Composite/CVBS Video & Component/YpPr Input, 1 x L/R Audio input for Composite/CVBS & Component YpPr |
| Sound Outputs                   | 1 x Digital Optical Audio output, 1 x 3.5mm Headphone  |
| Speaker*/ Amplifier Watts (RMS) | 2 x 10 / 2 x 8   |
| Voltage and power consumption   | AC 220V ~ 240V; 50Hz<br>110/145/180W (home mode/standard/max)<br>(<0.5W in Standby)  |
| Dimensions including stand (mm) | 1239W x 765H x 230D  |
| Net weight (Kgs)                | 15.7   |
| Wall Mounting                   | VESA 400 x 200 (mm)  |

\*\*Built-in Harman Kardon speaker systems (Full-range speaker and tweeter).

SOUND SYSTEM BY  
**harman/kardon**

Harman Kardon is trademark of HARMAN International Industries, Incorporated, registered in the United States and/or other countries.

**HDMI**

The terms HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

# SHARP

## Quick Start Set Up Guide

For information on using the TV's features, please refer to the Operating Instructions. (Available online to download.)

### Model Numbers

55BJ2K

55BJ3K

55BJ4K

55BJ5K

Register your manufacturers guarantee online within 14 days of purchase at [www.registertoday.co.uk/sharp](http://www.registertoday.co.uk/sharp) and enter into a prize draw to



### Quick & easy guide for setting up your TV

What is included in the box

Using the remote control

Setting up the TV for the first time - including attaching the stand

Connecting other devices to the Television

### Need help setting up or using your TV?

Please contact the UK & ROI Helpline\*

Telephone UK 0330 024 0803 or ROI 01443 3323

Online support at: [www.umc-uk.co.uk](http://www.umc-uk.co.uk)

Email support at: [service@umc-uk.co.uk](mailto:service@umc-uk.co.uk)

\*Calls to 0330 numbers are charged at standard call rates and are included as part of any bundled minutes with your phone provider.

Calls to the ROI number are charged at the local call rate.

The telephone opening hours are Monday to Friday 8.30am to 6pm, Saturday 9am – 5pm.

Bank Holidays - 10am to 4pm

Closed Christmas and New Years day



Please save your box/packaging as you will need this in the event of warranty/service repair or support. We are unable to carry out warranty/service if you are unable to package it correctly. The safest way to package your item in the event of warranty/service repair is in its original box/packaging.

**FreeviewHD**  
To receive Freeview HD channels, in particular Freeview HD channels, you will need a Digital TV aerial and be in a good Freeview coverage area.  
5. The Freeview Play Explore app features a carousel of genres to select from when searching for programmes, such as sport, comedy, dramas and soaps, etc. Content is made up from recommendations of the major broadcasters and offers an alternative means of searching.  
Note that to use the full functionality of Freeview Play your set must be connected to the internet.

**Microsoft PlayReady™**  
This product contains technology subject to certain intellectual property rights of Microsoft. Use or distribution of this technology outside of this product is prohibited without the appropriate license(s) from Microsoft. Content owners use Microsoft PlayReady™ content access technology to protect their intellectual property, including copyrighted content. This device uses PlayReady technology to access PlayReady-protected content and/or WDRM-protected content. If the device fails to properly enforce restrictions on content usage, content owners may require Microsoft to revoke the device's ability to consume PlayReady-protected content. Revocation should not affect unprotected content or content protected by other content access technologies. Content owners may require you to upgrade PlayReady to access their content. If you decline an upgrade, you will not be able to access content that requires the upgrade.



RF Cable

**Additional Accessories**  
Should you wish to connect older/analogue devices to your television, you can purchase the necessary cables either from your retailer or at [www.umc-uk.co.uk/cables](http://www.umc-uk.co.uk/cables)

- 1 x Quick Start Guide
- 1 x Remote Control and 2 x AAA Batteries
- 1 x Safety Leaflet
- 1 x Stand installation pack

## What is included in the box

Included with this TV are the following accessories

## Online Manual

To launch the Online Manual, press the [MENU] button and then select: Settings > About TV > Help Information > View Online Manual

## Using the remote control



- 1** STANDBY - Switch on the TV when in standby or vice versa. For models with USB Playback. For models with PVR Function. For models with integrated DVD players.
- 2** FREVIEW PLAY - Access the Freeview Play app.
- 2** NUMBER BUTTONS - 0-9 to select a TV channel directly. MUTE - Mute the sound or vice versa. TV GUIDE - Opens the 7 day TV guide (digital TV mode).
- 3** VOL (+/-) - To increase/decrease the sound level. PICTURE - Scrolls through picture mode options. SOUND - Scrolls through sound mode options. SOURCE - To display the input/source menu. CH (+/-) - To increase or decrease the channel being watched. MENU - To display OSD menu. EXIT - To exit all menus. (▲/▼/←/→/OK) - Allows you to navigate the on-screen menus and adjust the system settings to your preference. BACK - To go back a previous step. FAV - To display favourites menu.
- 4** INFO - Press once for now/next channel information. - Press twice for information about the current programme. TEXT - To enter/exit Text. SUBTITLE - To switch the dialogue at the bottom of the screen (on/off). TV - To switch to Digital Channels. YOUTUBE - Access the Youtube App. NETFLIX - Access the Netflix App. APPS - Access the APPS menu. RECORD - Access the USB record function. REC LIST - Opens the list of previously recorded items. - To restart the current chapter. - To advance forward to the next chapter. - To stop the playback/Eject Disc. (To EJECT the disc press/hold the ■ button for 4 seconds) - To play in fast forward mode. - To play in fast rewind mode. - To play/pause. - To go to a specific chapter. GOTO - To go to a set point, press a second time to return to point. ANGLE - Select different angle of DVD. REPEAT - To repeat playback.



## Sky Remote Code

If you wish to use your Sky remote to operate the TV's basic functions, you will need a Sky remote control (Revision 9 or later) and you will need to program it with the code 2134. If you wish to use your Sky Q remote to operate the TV's basic functions, you will need to program it with the code 4170.



# Setting up the TV set for the first time

## 1 Fitting the stand


TV panel must be facing downwards.

For the stand installation, there is one type of screw provided as shown below.


**Note:** To complete the stand installation you will require a cross head screw driver.



Place the TV set on a flat and clean surface with the panel facing downwards to avoid damage.



When the stand feet are installed correctly the stand feet will be longest at the front of the TV and shortest at the back with the feet pointing away from each other.




When the stand/feet are in the correct position, secure the feet to the underside of the TV set using 4 screws provided.

## Win a SHARP Soundbar

Register your manufacturers guarantee online within 14 days of purchase at [www.registertoday.co.uk/sharp](http://www.registertoday.co.uk/sharp) and enter into a prize draw to win a Sharp Soundbar. Terms and conditions apply. Online registration only.



## 2 Connecting your set




1) Connect the TV to your power socket.

2) If you wish to use the TV to receive Freeview/Saorview channels, connect the RF input from the TV to your outdoor Digital TV aerial. If you do not wish to receive Freeview/Saorview, skip this step.

## 3 Powering On the TV

TV Control Stick




Switch on the television by pressing the TV control stick located on the TV set.

Remote Control:  
Installing Batteries



Insert the batteries supplied into the remote control and press the standby button to power on the TV.

## Wall Mounting the TV



1. Remove the four screws that are supplied in the wall mounting holes.
2. The wall mount can now be easily attached to the mounting holes on the rear of the TV.
3. Install the wall mounting bracket to the television as advised by the bracket manufacturer.

Image for illustration only. For the dimensions of the VESA mounting, please refer to the Technical Specifications section of this document.

The picture shows the use of spacers, which are not applicable to all sets/installations.

## 4 First time installation

Basic installation steps are shown below. These may vary slightly depending on model.



Introduction

When the set first turns on, it enters the First Time Installation mode. This can be restarted by restoring the set to default settings in the 'About TV' Menu.

**Note:** In home mode, the TV will switch off automatically after 4 hours in the event that no buttons are pressed on the TV or remote control. (You can change this by pressing the [MENU] button and then selecting Settings>Time>Auto Standby)



Environment of Use

**Home Mode:** For normal use, by default it is set to a power saving mode which reduces the energy used by up to 25% (by reducing the power to the LED/LCD panel). This can be changed in the picture mode settings.



Default Source

Select the source which you use the most. If Digital TV (Freeview) is chosen, then at the next step, the set will tune in and default to Digital TV (Freeview). If one of the other sources is selected, then the set will not tune in at this stage and default to that input. If it is required to tune the set in later, press the [MENU] button and then select Settings>Channels



Languages

Select your preferred on-screen display language. This will change the language in which the menus and associated information is displayed in. When set up has been completed, to change this press the [MENU] button and then select Settings > System Menu > Language



Network setup

You can connect the TV to your broadband router or wireless network in order to take advantage of the Smart functions. If you connect the TV to your router using an Ethernet cable (recommended) this step will be skipped.




Tune in Channels

Choose to install terrestrial channels now or later.



Country Selection

Select the correct flag for the country in which the set will be used in. This will enable the set to correctly install the functions applicable in the country of use.



Set Up Netflix

If you have a Netflix account, it can be set up on the television here. Once set up and validated, the First Time Installation returns to the next step.




Support Advice

Information regarding support is displayed for a little while. Tuning continues and a progress bar is shown with the number of channels found indicated below.

If you are picking up signals from more than one transmitter, you will be requested to select your primary and secondary regions.

## Connectivity



|   |               |  |   |               |                                       |
|---|---------------|--|---|---------------|---------------------------------------|
| A | Ethernet/LAN* | Network connection                                   | I | SAT IN        | Satellite input                       |
| B | Digital Audio | Digital Optical Audio Output                         | J | RF in         | RF / TV aerial input                  |
| C | USB 1         | USB port 2.0   | K | HDMI 3        | HDMI input (ARC)                      |
| D | USB 2         | USB port 2.0   | L | USB 3         | USB port 2.0                          |
| E | L/R           | Audio shared for Video/Composite and component/YpBPr | M | CI card in    | Common interface module               |
| F | HDMI 1        | HDMI input   | N | SD            | SD card input                         |
| G | HDMI 2        | HDMI input   | O | Earphones     | Earphone input                        |
| H | Video/YpBPr   | Video Input (green) and HD input (YpBPr)             | P | Service Input | Input is used only by service centres |

\* The Ethernet/LAN port is used for Freeview HD services and smart functions.